



- NOTE(S):
1. ALL PIPING SHALL BE INSTALLED SO AS TO AVOID AIR TRAPS.
 2. ALL HORIZONTAL PIPING RUNS SHALL SLOPE UPWARD TOWARD THE INSTRUMENT CABINET.
 3. PRESSURE TAP LINES SHALL EXIT THE VAULT AT A POINT HIGHER THAN THE PROCESS CONNECTION.

DETAIL G

REV. 2004

CITY OF COLUMBUS, OHIO
 DEPARTMENT OF PUBLIC UTILITIES
 DIVISION OF WATER

APPROVED
RC Westerfield 1-21-05
 ADMINISTRATOR DATE

PRESSURE REDUCING VALVE
 PRESSURE TRANSMITTER
 PIPING SCHEMATIC

